



Your Metrologic MS9520 Laser has been pre-configured with the following settings:

(scan barcodes with a 3 second delay between reading each setup barcode)

START




Enter/Exit Configuration Mode



Recall Defaults



Enable Laser Emulation



One Shot Scanning



Minimum Symbol Length



Code Byte 0



Code Byte 0



Code Byte 1



Enter/Exit Configuration Mode

FINISH